CONTROL PANEL PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)

Microwave Oven
1.8 Cu. Ft.



Illus. No.	Part No.	DESCRIPTION
1		Literature
	8206416	U & C Guide
	8205607	Tech Sheet
	8205198	Cook Guide Label
2		Panel Asy, Control Includes Lens and Membrane Switch
	8206463	Black
	8206464	Stainless
3	8205378	Bracket, Control
4	8205379	Microcomputer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8184922	Pivot, Door
2		Handle, Door
	8205829	Black
	8206176	Stainless
3	8204678	Lower Hinge
4	8169479	Screw
5	8204690	Screw
6	8204691	Washer
7	8204679	Upper Hinge
8		Complete Door
	8206461	Black
	8206462	Stainless

INTERIOR AND VENTILATION PARTS

For Models: GH4184XSB1, GH4184XSS1

(BLACK) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1	8205096	Reflector, Lamp
2	8183993	Lamp
4	8184001	Filter, Grease
5	8205366	Plate, Bottom
6	8184141	Glass, Lamp
7	8184889	Holder, Glass
8	8206345	Switch, Micro Primary/Secondary
10	8206352	Switch, Micro
11	8169438	Spring, Interlock
12	8205211	Plate, Cam
13	8185189	Support, Interlock
14	8205362	Fan, DC 12 Volt
15	8205364	Housing, Fan
17	8205357	Diffuser, Housing
19	8185190	Rod−Locking Link
22	8206455	Plate, Side
24	8206347	Switch, Micro
25	8184202	Cover, Terminal
26	8184091	Motor, Capacitor
27	8184312	Holder, Fuse
28	4393308	Fuse
30	8184199	Screw
31	4393835	Screw
32	8184200	Screw
34	8169477	Screw
36	8169539	Holder, Lamp
37	8205146	Filter, Charcoal
38	8206456	Transformer, H.V.
39	8206457	Bracket, Capacitor
40	8206458	Capacitor, H.V.
41	8205361	Diode, H.V.
42	8206567	Chassis

AIR FLOW PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8205350	Deflector, Air
2	8206453	Cover, Lamp
3	8205368	Duct, Air
5	8183703	Thermostat
6	8204676	Cover
7	8183993	Lamp
8	8205354	Air Guide, Back

Illus. No.	Part No.	DESCRIPTION
9	8206175	Motor, Fan Assy
10	8205355	Shield
11	8206460	Shield
15	8169474	Screw
16		Air Guide
	8205367	Left
	8205352	Right

Illus. No.	Part No.	DESCRIPTION
17	8206446	Humidity, Sensor
18	8206624	Filter
19	8169539	Holder, Lamp
20	8205351	Base Plate, Air Guide
24	8185097	Socket, Motor Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND TURNTABLE PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8205044	Motor, Stirrer
2	8205202	Stirrer Shaft/Blade
3	8205369	Shield, Nomex
4	8206454	Thermostat/Bracket
5	8184476	Cover, Inlet Includes Nails and Bushings
6	8206118	Hook, Rack (4)
7	8184549	Nails/Bushings (4 of each)
8	8206226	Turntable
9	8206227	Ring, Turntable
10	W10107780	Spacer, Waterproof
11	8206228	Driver, Turntable
12	8183953	Motor, Turntable
13	W10110598	Cover, Terminal
14	8205363	Magnetron
15	8184951	Thermostat
16	8205549	Rack
18	4393838	Screw
21	4393832	Screw
25	8205039	Spacer (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND INSTALLATION PARTS

For Models: GH4184XSB1, GH4184XSS1
(BLACK) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8206315	Plate, Mounting
4	8184897	Lid, Power Cord
5	8206442	Damper Assembly
6	8205808	Cord, Power
7	8205348	Case, Outer

Illus. No.	Part No.	DESCRIPTION
8	8205215	Grille, Vent
9	8184190	Clip, Grille
10	4393836	Screw
11	8169475	Screw
12	4393472	Screw
18	8206452	Plate, Damper

Illus. No.	Part No.	DESCRIPTION

FOLLOWING PARTS NOT ILLUSTRATED

Miscellaneous

8205948	Installation, Hardware
8184731	Template, Upper
8169704	Screw, Top Mountng
8205696	Ground Wire
8205693	H.V. Wire Assembly
8206195	Main Wire Assy
W10111829	Wire−Grnd,Thrmst
W10111830	Wire−Grnd, Sensor
W10111831	Wire−Grnd, AC Line
W10111832	Wire−Grnd, Cavity
W10111833	Wire−Grnd, Fuse

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST